



# SolvisMax Hauptschalter – Montage

**Main Switch Installation / Montaggio dei interruttore principale / Montaje de interruptor principal/ Montagem da interruptor principal/ Montage d'interrupteur principal**



**Stecker / Plug / Connettore /  
Conectore / Ficha / Connecteur**

**Schalter / Switch / Interruttore / Interruptor  
Interruptor / Interrupteur**

## Elektrischer Anschluss / Electrical Connection / Allacciamento elettrico / Conexión eléctrica / Ligação eléctrica / Raccordement électrique

|           | ①       | ②    | ③            | ④                     |
|-----------|---------|------|--------------|-----------------------|
| <b>DE</b> | schwarz | blau | blau-weiß    | schwarz-weiß          |
| <b>EN</b> | black   | blue | blue-white   | black-white           |
| <b>IT</b> | nero    | blu  | blu-sappi    | nero-sappi            |
| <b>ES</b> | negro   | azul | azul lo sabe | blanco de - y - negro |
| <b>PT</b> | preto   | azul | azul-saiba   | branco e preto        |
| <b>FR</b> | noir    | bleu | bleu-blanc   | noir-blanc            |



**Item no.: 14593**

**L 48-M**

Subject to technical changes  
02.17 / 14593-2b

SOLVIS GmbH • Grottrian-Steinweg-Straße 12 • 38112 Braunschweig  
Tel.: 0531 28904-0 • Fax: 0531 28904-100 • [www.solvis.de](http://www.solvis.de)